

Never Fear ... Player Instructions Are Here!



# CHAMPION II



## HOW TO BEGIN

- Log on to **Video King's Champion II™** tablet by entering the **Account Number** printed on your receipt. (Enter **PIN** if required.) Remember to hang on to your receipt until all play is finished, and you are ready to cash in your credits.
- If you need assistance at any time during play, press the **"Help"** or **"?"** buttons.
- If you need to temporarily stop play, press the **"Terminal Lockout"** button on the **Main Menu**.
- To resume play, simply re-enter your **Account Number**.

## TO PLAY LIVE BINGO

- Press the **"Live Bingo"** button on the **Main Menu**.
- To dab your cards, touch the bingo ball shown in the lower right corner after each call is made.
- To change the number of cards viewed, touch the **Eye Glasses** button and from **"Bingo Views,"** make your selection.
- To view more of your cards, touch the **"Page"** button. For further game information, touch the **Prize** button.
- To return to the **Main Menu**, touch the **Home or House** button.

## TO PLAY HURRICANE BONANZA, BUCCANEER BONANZA, NERO'S COLISEUM AND MAYAN GOLD

- Select the game you wish to play from the **Main Menu**.
- Press the **"Dab"** button below the flashboard, then press **"Play."**
- Press the **Up or Down** arrows to select the card price or wager.
- For **Nero's Coliseum** or **Mayan Gold**, you can select from 1 to 4 cards.
- Press **"Play"** to start game. The cards will be revealed and numbers dabbled automatically.
- If you have **Bingo**, **"S"** signs or other game specific symbols will highlight the winning pattern.
- The amount won will appear in the **Patterns** panel and credits added.
- To choose a different game, press the **"Menu"** button for other options.

## TO PLAY BOTH LIVE BINGO AND 24-NUMBER GAMES

- While in **Live Bingo**, touch the **Eye Glasses** button.
- In the **"Games Views"** panel, select the game you wish to play.
- Your **Live Bingo** cards will be shown to the right of the screen, while you play the other games.

## TO PLAY K9 CASH

- On the **Main Menu**, press the **"K9 Cash"** button.
- Press the **Up or Down** arrows to select the card price or wager.
- Touch the screen to select the number of cards (from 1 to 9) you wish to play. Simply re-press to deselect. The number of active cards will be shown in the **Dog Bowl** at the bottom of the screen.
- Press the **Dog Bowl** to begin game.
- As balls are called, the card borders will change from grey to blue, indicating one-away, to red, indicating a win.
- If you have **Bingo**, press **"Accept Win,"** and your credits will stockpile in the dog bone.



# Video King®

www.videokingnetwork.com (800) 635-9912 (402) 951-2970